



ASSEMBLY INSTRUCTION

JF701 - 1300mm Corner TV Stand


HELP LINE NUMBER : 01443 816982

A		Allen Key - M4	1PC				
B		Allen Key - M5	1PC				
C		Washer - 5/16" data-bbox="173 203 405 218"/>	4PC				
D		Bolt - Ø5/16" data-bbox="188 228 375 243"/>	4PC				
E		Bolt - Ø1/4" data-bbox="193 253 370 268"/>	12PC				
F		Foot - Ø1/4" data-bbox="193 278 373 293"/>	2PC	K		Right Leg	1PC
G		Cam Dowel	4PC	L		Metal Support Bars	2PC
H		Metal Dowel	4PC	M		Bottom Panel	1PC
I		Cam Lock - Ø15*12mmL	4PC	N		Top Panel	1PC
J		Left Leg	1PC	O		Back Panel	1PC

STEP1



STEP2



STEP3

