



ASSEMBLY INSTRUCTION

JF702 - 1300 Rectangular TV Stand


HELP LINE NUMBER : 01443 816982

A		Allen Key - M5	1PC				
B		Chrome Nut - Ø25*15mmL	4PC				
C		Washer - 5/16''*19*1.5mmL	4PC				
D		Bolt - Ø5/16''*32mmL	4PC				
E		Cam Dowel	4PC				
F		Metal Dowel	4PC				
G		Cam Lock	4PC	I		Top Panel	1PC
H		Left & Right Legs	2PC	J		Bottom Panel	1PC
				K		Back Panel	1PC

STEP1



STEP2



STEP3

